

Гидравлические детали KAWASAKI

Технические характеристики

По вопросам продаж и поддержки обращайтесь:

Алматы (727)345-47-04
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922)49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Ноябрьск (3496)41-32-12
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37
Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Саранск (8342)22-96-24
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Сыктывкар (8212)25-95-17
Тамбов (4752)50-40-97
Тверь (4822)63-31-35

Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Улан-Удэ (3012)59-97-51
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +(727)345-47-04

Беларусь +(375)257-127-884


Узбекистан +998(71)205-18-59

Киргизия +996(312)96-26-47

эл.почта: syz@nt-rt.ru || сайт: <https://skshydraulic.nt-rt.ru/>

K3SP36C(SDV36)8T MAIN PUMP


(KAWASAKI)K3SP36C(SDV36)8T MAIN PUMP



ITEM	DESCRIPTION	QUANTITY
1	VALVE PLATE	1
2	CYLINDER BLOCK	1
3	BALL GUIDESPRING	10
4	BALL GUIDE	1
5	RETAINER PLATE	1
6	PISTON SHOE	10
7	SWASH PLATE	1
8	YOKE BALL LEFT	1
9	YOKE BALL RIGHT	1
10	DRIVE SHAFT	1
11	COUPLING	1
12	CHARGE PUMP	1

K3VL45/80


(KAWASAKI)K3VL45/80



ITEM	DESCRIPTION	QUANTITY
1	VALVE PLATE	1
2	CYLINDER BLOCK	1
3	BALL GUIDE	1
4	RETAINER PLATE	1
5	PISTON SHOE	9
6	THRUST PLATE	1
7	SWASH PLATE	1
8	SUPPORT	1
9	DRIVE SHAFT	1
10	SWASH PLATE SLEEVE	1

K7V63


(KAWASAKI)K7V63



ITEM	DESCRIPTION	QUANTITY
1	VALVE PLATE	2
2	CYLINDER BLOCK	2
3	BALL GUIDESPRING	12
4	BALL GUIDE	2
5	RETAINER PLATE	2
6	PISTON SHOE	18
7	THRUST PLATE	2
8	SWASH PLATE	2
9	SWASH PLATE SLEEVE	2
10	SUPPORT	2
11	DRIVE SHAFT	2

NV64/NV84/NV111DT/NV137/NV172/NV270


(KAWASAKI)NV64/NV84/NV111DT/NV137/NV172/NV270



ITEM	DESCRIPTION	QUANTITY
1	VALVE PLATE LEFT	1
	VALVE PLATE RIGHT	1
2	CYLINDER BLOCK	2
3	DISC SPRING	8
4	BALL GUIDE?	2
5	PISTON SHOE	18
6	RETAINER PLATE	2
7	SWASH PLATE	2
8	SUPPORT	2
9	DRIVE SHAFT FRONT	1
	DRIVE SHAFT REAR	1

NX15


(KAWASAKI)NX15



ITEM	DESCRIPTION	QUANTITY
1	VALVE PLATE	1
2	CYLINDER BLOCK	1
3	DISC SPRING	4
4	BALL GUIDE	1
5	RETAINER PLATE	1
6	PISTON SHOE	9
7	THRUST PLATE	1
8	DRIVE SHAFT	1

NVK45(KOBELCO EXCAVATOR)


(KAWASAKI)NVK45(KOBELCO EXCAVATOR)



ITEM	DESCRIPTION	QUANTITY
1	DRIVE SHAFT	2
2	VALVE PLATE LEFT	1
	VALVE PLATE RIGHT	1
3	CYLINDER BLOCK	2
4	PRESS PIN	12
5	BALL GUIDE	2
6	PISTON SHOE	18
7	RETAINER PLATE	2
8	THRUST PLATE	2

K3V63DT~180DT/280/G280/G180/K5V80~200


(KAWASAKI)K3V63DT(K3V63BDT)/K3V112DT/K3V140DT/K3V180DT/K3V280/K3VG280/K3VG180/K5V80/K5V140(DOOSAN 300-7)/K5V160(HYUNDAI 300-6 MAIN PUMP)/K5V200(JAPAN 450/470、CASE 470、CASE 480 MAIN PUMP)



ITEM	DESCRIPTION	QUANTITY
1	VALVE PLATE	2
2	CYLINDER BLOCK	2
3	WASHER	2
4	BALL GUIDE	2
5	RETAINER PLATE	2
6	PISTON SHOE	18
7	THRUST PLATE	2
8	SWASH PLATE	2
9	SUPPORT	2
10	DRIVE SHAFT FRONT/REAR	1/1
11	SERVO BLOCK	2
12	CHARGE PUMP 2 HOLES	1
13	CHARGE PUMP 5 HOLES	1
14	PILOT VALVE	1

KVC925/KVC930/KVC932

(KAWASAKI)KVC925/KVC930/KVC932



ITEM	DESCRIPTION	QUANTITY
1	VALVE PLATE	1
2	SNAP RING	1
3	WASHER	2
4	SPRING	1
5	CYLINDER BLOCK	1
6	PISTON SHOE	9
7	AXIAL SHAFT	2
8	RETAINER	1
9	THRUST PLATE	1
10	SWASH PLATE	1
11	DRIVE SHAFT	1

По вопросам продаж и поддержки обращайтесь:

Алматы (727)345-47-04
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922)49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Ноябрьск (3496)41-32-12
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37
Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Саранск (8342)22-96-24
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Сыктывкар (8212)25-95-17
Тамбов (4752)50-40-97
Тверь (4822)63-31-35

Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Улан-Удэ (3012)59-97-51
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +(727)345-47-04

Беларусь +(375)257-127-884

Узбекистан +998(71)205-18-59

Киргизия +996(312)96-26-47

эл.почта: syz@nt-rt.ru || сайт: <https://skshydraulic.nt-rt.ru/>