

Гидравлические детали КУВ

Технические характеристики

По вопросам продаж и поддержки обращайтесь:

Алматы (727)345-47-04
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922)49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Ноябрьск (3496)41-32-12
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37
Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Саранск (8342)22-96-24
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Сыктывкар (8212)25-95-17
Тамбов (4752)50-40-97
Тверь (4822)63-31-35

Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Улан-Удэ (3012)59-97-51
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +(727)345-47-04

Беларусь +(375)257-127-884


Узбекистан +998(71)205-18-59

Киргизия +996(312)96-26-47

эл.почта: syz@nt-rt.ru || сайт: <https://skshydraulic.nt-rt.ru/>

PSVD2-16E/21E/26E/27E/PSVD2-21/SVD22/PSVL-54


(KYB)PSVD2-16E/21E/26E/27E/PSVD2-21E(KYB)4T/SVD22/PSVL-54



ITEM	DESCRIPTION	QUANTITY
1	VALVE PLATE	1
2	SNAP RING	1
3	WASHER	2
4	SPRING	1
5	CYLINDER BLOCK	1
6	PRESS PIN	3
7	BALL GUIDE	1
8	RETAINER PLATE	1
9	PISTON SHOE	10
10	SWASH PLATE	1
11	DRIVE SHAFT	1
12	CHARGE PUMP	1

PSV2-55T(KYB)SUMITOMO 120


(KYB)PSV2-55T SUMITOMO 120



ITEM	DESCRIPTION	QUANTITY
1	VALVE PLATE	1
2	CYLINDER BLOCK	1
3	DISC SPRING	4
4	BALL GUIDE	1
5	PISTON SHOE	9
6	RETAINER PLATE	1
7	SWASH PLATE	1
8	SADDLE BEARING	2
9	SADDLE BEARING	2
10	LOCATING PIN	2
11	DRIVE SHAFT	1
12	SLIDE BLOCK	1
13	CHARGE PUMP	1

PSV2-55T(KYB)SUMITOMO 120


(KYB)PSV2-55T SUMITOMO 120



ITEM	DESCRIPTION	QUANTITY
1	VALVE PLATE	1
2	CYLINDER BLOCK	1
3	DISC SPRING	4
4	BALL GUIDE	1
5	PISTON SHOE	9
6	RETAINER PLATE	1
7	SWASH PLATE	1
8	SADDLE BEARING	2
9	SADDLE BEARING	2
10	LOCATING PIN	2
11	DRIVE SHAFT	1
12	SLIDE BLOCK	1
13	CHARGE PUMP	1

MSF-85/GMY18


(KYB)MSF-85/GMY18



ITEM	DESCRIPTION	QUANTITY
1	VALVE PLATE MOTOR	1
2	SNAP RING	1
3	COIL SPRING	1
4	WASHER	2
5	CYLINDER BLOCK	1
6	PRESS PIN	3
7	BALL GUIDE	1
8	PISTON SHOE	9
9	RETAINER PLATE	1
10	SWASH PLATE	1
11	DRIVE SHAFT	1
12	PIN	1

KMF40/40-2/90/KMF105


(KYB)KMF40/KMF40-2/KMF90(KPV90)PC200-1/2/3/KMF105



ITEM	DESCRIPTION	QUANTITY
1	VALVE PLATE	1
2	CYLINDER BLOCK	1
3	COIL SPRING	1
4	SLEEVE	1
5	RETAINER PLATE	1
6	SPHERICAL WASHER	7
7	PISTON	7
8	DRIVE SHAFT	1
9	LOCATING PIN	1
10	CENTER BALL	1
11	CENTER PIN	1

KYB33/KYB36/KYB87/KYB90(MSG-60P)


(KYB)KYB33/KYB36/KYB87/KYB90(MSG-60P)



ITEM	DESCRIPTION	QUANTITY
1	VALVE PLATE	1
2	SLEEVE	1
3	CYLINDER BLOCK	1
4	COIL SPRING	1
5	PISTON	7
6	RETAINER PLATE	1
7	SPHERICAL WASHER	7
8	CENTER PIN	1
9	DRIVE SHAFT	1
10	SADDLE BEARING	2

MSG-27P(KYB)/(LSGMF27/10W)/MSG-44P(KYB)/LSGMF44/10W-R21


(KYB)MSG-27P(KYB)/(LSGMF27/10W)/MSG-44P(KYB)/LSGMF44/10W-R21



ITEM	DESCRIPTION	QUANTITY
1	VALVE PLATE	1
2	SNAP RING	1
3	WASHER	2
4	SPRING	1
5	FRICTION PLATE	3
6	SEPERATION PLATE	2
7	CYLINDER BLOCK	1
8	PRESS PIN	3
9	BALL GUIDE	1
10	RETAINER PLATE	1
11	PISTON SHOE	9
12	THRUST PLATE	1
13	DRIVE SHAFT	1


MAG-33VP-480E-2(4-5.5T TRAVEL MOTORT)

(KYB)MAG-33VP-480E-2(4-5.5T TRAVEL MOTORT)



ITEM	DESCRIPTION	QUANTITY
1	VALVE PLATE	1
2	SNAP RING	1
3	SPRING	1
4	WASHER	2
5	CYLINDER BLOCK	1
6	PRESS PIN	3
7	BALL GUIDE	1
8	PISTON SHOE	9
9	RETAINER PLATE	1
10	SWASH PLATE	1
11	PRESS BALL	2
12	DRIVE SHAFT	1

V25
(KYB)V25



ITEM	DESCRIPTION	QUANTITY
1	VALVE PLATE	1
2	CYLINDER BLOCK	1
3	BALL GUIDE	1
4	RETAINER PLATE	1
5	PISTON SHOE	9
6	THRUST PLATE	1

По вопросам продаж и поддержки обращайтесь:

Алматы (727)345-47-04
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922)49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Ноябрьск (3496)41-32-12
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37
Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Саранск (8342)22-96-24
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Сыктывкар (8212)25-95-17
Тамбов (4752)50-40-97
Тверь (4822)63-31-35

Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Улан-Удэ (3012)59-97-51
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +(727)345-47-04

Беларусь +(375)257-127-884

Узбекистан +998(71)205-18-59

Киргизия +996(312)96-26-47

эл.почта: syz@nt-rt.ru || сайт: <https://skshydraulic.nt-rt.ru/>