

Гидравлические детали VICKERS, YUKEN

Технические характеристики

По вопросам продаж и поддержки обращайтесь:

Алматы (727)345-47-04
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922)49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Ноябрьск (3496)41-32-12
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37
Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Саранск (8342)22-96-24
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Сыктывкар (8212)25-95-17
Тамбов (4752)50-40-97
Тверь (4822)63-31-35

Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Улан-Удэ (3012)59-97-51
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +(727)345-47-04

Беларусь +(375)257-127-884


Узбекистан +998(71)205-18-59

Киргизия +996(312)96-26-47

эл.почта: syz@nt-rt.ru || сайт: <https://skshydraulic.nt-rt.ru/>

VOLVO/F11-005~250/F12-060/080/110-MF-1H


(PARKER)VOLVO/F11-005/F11-010/F11-020/F11-28/F11-39/F11-58/F12-060/F12-080/F12-090/F12-110-MF-1H/F11-150/F11-250



ITEM	DESCRIPTION	QUANTITY
1	VALVE PLATE	1
2	CYLINDER BLOCK	1
3	PISTON SHOE	5
4	CENTER PIN	1
5	DRIVE SHAFT	1
6	DRIVE SHAFT KEY	1
7	DRIVEN SHAFT	1

PVSO250


(PARKER)PVXS130/PVXS180/PVXS250/PVSO250/PV180/PV250/PLV250



ITEM	DESCRIPTION	QUANTITY
1	VALVE PLATE	1
2	CYLINDER BLOCK	1
3	PISTON SHOE	9
4	RETAINER PLATE	1
5	RETAINER	2
6	DRIVE SHAFT	1
7	RETAINER	1
8	SADDLE BEARING	2

PVM-018/PVM-028


(PARKER)PVM-018/PVM-028



ITEM	DESCRIPTION	QUANTITY
1	VALVE PLATE	1
2	SNAP RING	1
3	SPRING	1
4	WASHER	2
5	CYLINDER BLOCK	1
6	BACK-UP RING	1
7	PRESS PIN	3
8	BALL GUIDE	1
9	PISTON SHOE	9
10	RETAINER PLATE	1
11	SWASH PLATE	1
12	SADDLE BEARING	2
13	CENTER PIN	1
14	YOKE BALL	1
15	BALL SUPPORT	1


BMHQ30/PV180 PARKER

(PARKER)BMHQ30/PV180 PARKER




ITEM	DESCRIPTION	QUANTITY
1	VALVE PLATE	1
2	SNAP RING	1
3	WASHER	2
4	SPRING	1
5	CYLINDER BLOCK	1
6	RETAINER	2
7	SPACER	4
8	PISTON SHOE	9
9	RETAINER PLATE	4
10	LOCATING PIN	1
11	SWASH PLATE	1
12	DRIVE SHAFT	1

PAVC38/PAVC65/PAVC100 PARKER
(PARKER)PAVC38/PAVC65/PAVC100 PARKER




ITEM	DESCRIPTION	QUANTITY
1	VALVE PLATE	1
2	BALL GUIDE	1
3	RETAINER PLATE	1
4	PISTON SHOE	7

PARKER 2145/P2145 PARKER 23/P2075/PARKER 270/PV270/P2105/P2060
(PARKER)2145/P2145 PARKER 23/P2075/PARKER 270/PV270/P2105/P2060




ITEM	DESCRIPTION	QUANTITY
1	VALVE PLATE	1
2	SNAP RING	1
3	SPRING	1
4	WASHER	2
5	CYLINDER BLOCK	1
6	RETAINER	2
7	RETAINER PLATE	1
8	PISTON SHOE	9
9	SWASH PLATE	1
10	YOKE PISTON	1
11	SADDLE BEARING	2
12	DRIVE SHAFT	1

PV29/PV74
(PARKER)PV29/PV74



ITEM	DESCRIPTION	QUANTITY
1	VALVE PLATE	1
2	SNAP RING	1
3	SPRING	1
4	WASHER	2
5	CYLINDER BLOCK	1
6	PRESS PIN	3
7	BALL GUIDE	1
8	RETAINER PLATE	1
9	PISTON SHOE	9
10	THRUST PLATE	1
11	DRIVE SHAFT	1


PVG130 B
(PARKER)PVG130 B



ITEM	DESCRIPTION	QUANTITY
1	CYLINDER BLOCK	1
2	BALL GUIDE	1
3	PISTON SHOE	9
4	RETAINER PLATE	1
5	DRIVE SHAFT	1

PVT38/PVT64


(PARKER)PVT38/PVT38 NEW DESIGN/PVT64



ITEM	DESCRIPTION	QUANTITY
1	VALVE PLATE	1
2	SNAP RING	1
3	SPRING	1
4	WASHER	2
5	CYLINDER BLOCK	1
6	PRESS PIN	3
7	BALL GUIDE	1
8	RETAINER PLATE	1
9	PISTON SHOE	9
10	SERVO PISTON	1
11	SWASH PLATE	1
12	SADDLE BEARING	2


SH5V/131

(PARKER)SH5V/131



ITEM	DESCRIPTION	QUANTITY
1	BEARING PLATE	1
2	VALVE PLATE	1
3	CYLINDER BLOCK	1
4	PISTON SHOE	9
5	RETAINER	1
6	RETAINER PLATE	1
7	RETAINER 2	2
8	RETAINER 1	2

A16/A22/A37/A45/A56/A70/A90/A145
(YUNKEN)A16/A22/A37/A45/A56/A70/A90/A145



ITEM	DESCRIPTION	QUANTITY
1	VALVE PLATE	1
2	SNAP RING	1
3	SPRING	1
4	WASHER	2
5	CYLINDER BLOCK	1
6	PRESS PIN	3
7	BALL GUIDE	1
8	RETAINER PLATE	1
9	PISTON SHOE	9
10	THRUST PLATE	1
11	DRIVE SHAFT	1

По вопросам продаж и поддержки обращайтесь:

Алматы (727)345-47-04
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922)49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Ноябрьск (3496)41-32-12
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37
Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Саранск (8342)22-96-24
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Сыктывкар (8212)25-95-17
Тамбов (4752)50-40-97
Тверь (4822)63-31-35

Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Улан-Удэ (3012)59-97-51
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +(727)345-47-04

Беларусь +(375)257-127-884

Узбекистан +998(71)205-18-59

Киргизия +996(312)96-26-47

эл.почта: syz@nt-rt.ru || сайт: <https://skshydraulic.nt-rt.ru/>